



ORDER INSTRUCTIONS

1. Choose your part number.
2. Fill in blank [] with your desired length in inches.
3. See page 19 for Standard Specifications.

Custom Assemblies — We will assemble ANY manufacturer's connector to ANY cable length.



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|--------------|-------------|------------|
| RG-55B/U | RFW-3298 | [inches] |
| RG-58A/U | RFW-3299 | [inches] |
| RG-58C/U | RFW-5362 | [inches] |
| RG-142B/U | RFW-3877 | [inches] |
| RG-223/U | RFW-5099 | [inches] |
| RG-400/U | RFW-3300 | [inches] |
| BELDEN 7806A | RFW-0340 | [inches] |
| BELDEN 7807A | RFW-0553 | [inches] |
| LMR-195 | RFW-3301 | [inches] |
| LMR-200 | RFW-3302 | [inches] |
| WBC-195 | RFW-1372 | [inches] |
| WBC-200 | RFW-1585 | [inches] |




Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|--------------|-------------|------------|
| RG-8/X | RFW-3303 | [inches] |
| RG-55B/U | RFW-3304 | [inches] |
| RG-58A/U | RFW-5791 | [inches] |
| RG-58C/U | RFW-3305 | [inches] |
| RG-142B/U | RFW-7466 | [inches] |
| RG-223/U | RFW-3306 | [inches] |
| RG-400/U | RFW-3307 | [inches] |
| BELDEN 7806A | RFW-0341 | [inches] |
| BELDEN 7807A | RFW-0554 | [inches] |
| BELDEN 7808A | RFW-0756 | [inches] |
| LMR-195 | RFW-3308 | [inches] |
| LMR-200 | RFW-3309 | [inches] |
| LMR-240 | RFW-3310 | [inches] |
| LMR-240UF | RFW-3311 | [inches] |
| WBC-195 | RFW-1373 | [inches] |
| WBC-200 | RFW-1586 | [inches] |
| WBC-240 | RFW-1788 | [inches] |

SMB

SMB Jack to SMB Jack



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-5114 | [inches] |
| RG-188A/U | RFW-5115 | [inches] |
| RG-188-DS | RFW-5116 | [inches] |
| RG-316/U | RFW-5117 | [inches] |
| RG-316-DS | RFW-5119 | [inches] |
| BELDEN 7805 | RFW-4924 | [inches] |
| LMR-100A | RFW-5120 | [inches] |
| WBC-100 | RFW-10388 | [inches] |

SMB Jack to SMB R/A Plug



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-5107 | [inches] |
| RG-188A/U | RFW-5108 | [inches] |
| RG-188-DS | RFW-5109 | [inches] |
| RG-316/U | RFW-5110 | [inches] |
| RG-316-DS | RFW-5111 | [inches] |
| BELDEN 7805 | RFW-4925 | [inches] |
| LMR-100A | RFW-5112 | [inches] |
| WBC-100 | RFW-10389 | [inches] |

SMB Jack to BNC Female Bulkhead



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3722 | [inches] |
| RG-188A/U | RFW-3723 | [inches] |
| RG-188-DS | RFW-3724 | [inches] |
| RG-316/U | RFW-3725 | [inches] |
| RG-316-DS | RFW-3726 | [inches] |
| BELDEN 7805 | RFW-4922 | [inches] |
| LMR-100A | RFW-3727 | [inches] |
| WBC-100 | RFW-10386 | [inches] |

SMB Jack to Mini-UHF Female



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3915 | [inches] |
| RG-188A/U | RFW-3916 | [inches] |
| RG-188-DS | RFW-3917 | [inches] |
| RG-316/U | RFW-3918 | [inches] |
| RG-316-DS | RFW-3919 | [inches] |
| BELDEN 7805 | RFW-4685 | [inches] |
| LMR-100A | RFW-3924 | [inches] |
| WBC-100 | RFW-10150 | [inches] |


SMB Gold Jack to MMCX R/A Gold Plug



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3964 | [inches] |
| RG-188A/U | RFW-3965 | [inches] |
| RG-316/U | RFW-3966 | [inches] |
| BELDEN 7805 | RFW-4917 | [inches] |
| LMR-100A | RFW-3967 | [inches] |
| WBC-100 | RFW-10381 | [inches] |

SMB Bulkhead Jack to SMB Bulkhead Jack



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|--------------|-------------|------------|
| RG-174A/U | RFW-3976 | [inches] |
| RG-188A/U | RFW-3977 | [inches] |
| RG-188-DS | RFW-3978 | [inches] |
| RG-316/U | RFW-3979 | [inches] |
| RG-316-DS | RFW-3980 | [inches] |
| BELDEN 7806A | RFW-0346 | [inches] |
| LMR-195 | RFW-3981 | [inches] |
| WBC-195 | RFW-1378 | [inches] |

SMB Bulkhead Jack to SMB R/A Gold Jack




Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3982 | [inches] |
| RG-188A/U | RFW-3983 | [inches] |
| RG-316/U | RFW-3984 | [inches] |
| BELDEN 7805 | RFW-4913 | [inches] |
| LMR-100A | RFW-3985 | [inches] |
| WBC-100 | RFW-10377 | [inches] |

ORDER INSTRUCTIONS

1. Choose your part number.
2. Fill in blank [] with your desired length in inches.
3. See page 19 for Standard Specifications.

Custom Assemblies — We will assemble ANY manufacturer's connector to ANY cable length.




SMB Bulkhead Jack to SMB R/A Plug



Fill in blank [inches]with your desired length in inches

| Cable Type | Part Number - Length |
|--------------|----------------------------|
| RG-174A/U |RFW-5896- [inches] |
| RG-188A/U |RFW-5283- [inches] |
| RG-188A/U DS |RFW-5898- [inches] |
| RG-316/U |RFW-5895- [inches] |
| RG-316-DS |RFW-5899- [inches] |
| BELDEN 7805 |RFW-4926- [inches] |
| LMR-100A |RFW-5897- [inches] |
| WBC-100 |RFW-10390- [inches] |

SMB Bulkhead Jack to MCX R/A Gold Plug



Fill in blank [inches]with your desired length in inches

| Cable Type | Part Number - Length |
|-------------|----------------------------|
| RG-174A/U |RFW-3968- [inches] |
| RG-188A/U |RFW-3969- [inches] |
| RG-316/U |RFW-3970- [inches] |
| BELDEN 7805 |RFW-4910- [inches] |
| LMR-100A |RFW-3971- [inches] |
| WBC-100 |RFW-10374- [inches] |

SMB Bulkhead Jack to MMCX R/A Gold Plug



Fill in blank [inches]with your desired length in inches

| Cable Type | Part Number - Length |
|-------------|----------------------------|
| RG-174A/U |RFW-3972- [inches] |
| RG-188A/U |RFW-3973- [inches] |
| RG-316/U |RFW-3974- [inches] |
| BELDEN 7805 |RFW-4911- [inches] |
| LMR-100A |RFW-3975- [inches] |
| WBC-100 |RFW-10375- [inches] |


SMB Plug to SMB Bulkhead Jack



Fill in blank [inches]with your desired length in inches

| Cable Type | Part Number - Length |
|--------------|----------------------------|
| RG-174A/U |RFW-5280- [inches] |
| RG-188A/U |RFW-5281- [inches] |
| RG-188A/U DS |RFW-5893- [inches] |
| RG-316/U |RFW-5282- [inches] |
| RG-316-DS |RFW-5894- [inches] |
| BELDEN 7805 |RFW-4933- [inches] |
| LMR-100A |RFW-5892- [inches] |
| WBC-100 |RFW-10397- [inches] |

SMB Plug to SMB Jack



Fill in blank [inches]with your desired length in inches

| Cable Type | Part Number - Length |
|--------------|----------------------------|
| RG174A/U |RFW-5100- [inches] |
| RG188A/U |RFW-5101- [inches] |
| RG-188A/U DS |RFW-5102- [inches] |
| RG316/U |RFW-5103- [inches] |
| RG-316-DS |RFW-5104- [inches] |
| BELDEN 7805 |RFW-4932- [inches] |
| LMR-100A |RFW-5105- [inches] |
| WBC-100 |RFW-10396- [inches] |

SMB Gold Plug to SMB Gold Jack

| | |
|-------------|----------------------------|
| RG-174A/U |RFW-4446- [inches] |
| RG-188A/U |RFW-4447- [inches] |
| RG-316/U |RFW-5455- [inches] |
| BELDEN 7805 |RFW-4920- [inches] |
| LMR-100A |RFW-4448- [inches] |
| WBC-100 |RFW-10384- [inches] |

SMB Plug to SMB Plug



Fill in blank [inches]with your desired length in inches

| Cable Type | Part Number - Length |
|--------------|----------------------------|
| RG-174A/U |RFW-5284- [inches] |
| RG-188A/U |RFW-5285- [inches] |
| RG-188A/U DS |RFW-5901- [inches] |
| RG-316/U |RFW-5286- [inches] |
| RG-316-DS |RFW-5902- [inches] |
| BELDEN 7805 |RFW-4934- [inches] |
| LMR-100A |RFW-5900- [inches] |
| WBC-100 |RFW-10398- [inches] |

SMB Gold Plug to SMB Gold Plug

| | |
|-------------|----------------------------|
| RG-174A/U |RFW-4449- [inches] |
| RG-188A/U |RFW-4450- [inches] |
| RG-316/U |RFW-5629- [inches] |
| BELDEN 7805 |RFW-4921- [inches] |
| LMR-100A |RFW-4451- [inches] |
| WBC-100 |RFW-10385- [inches] |

SMB Plug to SMB R/A Plug



Fill in blank [inches]with your desired length in inches

| Cable Type | Part Number - Length |
|--------------|----------------------------|
| RG-174A/U |RFW-5277- [inches] |
| RG-188A/U |RFW-5889- [inches] |
| RG-188A/U DS |RFW-5891- [inches] |
| RG-316/U |RFW-5279- [inches] |
| RG-316-DS |RFW-5890- [inches] |
| BELDEN 7805 |RFW-4935- [inches] |
| LMR-100A |RFW-5888- [inches] |
| WBC-100 |RFW-10399- [inches] |

SMB Plug to MCX R/A Gold Plug



Fill in blank [inches]with your desired length in inches

| Cable Type | Part Number - Length |
|-------------|----------------------------|
| RG-174A/U |RFW-3920- [inches] |
| RG-188A/U |RFW-3921- [inches] |
| RG-316/U |RFW-3922- [inches] |
| BELDEN 7805 |RFW-4927- [inches] |
| LMR-100A |RFW-3923- [inches] |
| WBC-100 |RFW-10391- [inches] |

SMB Gold Plug to MMCX R/A Gold Plug



Fill in blank [inches]with your desired length in inches

| Cable Type | Part Number - Length |
|-------------|----------------------------|
| RG-174A/U |RFW-3932- [inches] |
| RG-188A/U |RFW-3933- [inches] |
| RG-316/U |RFW-3934- [inches] |
| BELDEN 7805 |RFW-4929- [inches] |
| LMR-100A |RFW-3935- [inches] |
| WBC-100 |RFW-10393- [inches] |

SMB Plug to SMA Female




Fill in blank [inches]with your desired length in inches

| Cable Type | Part Number - Length |
|-------------|----------------------------|
| RG-174A/U |RFW-5048- [inches] |
| RG-188A/U |RFW-3879- [inches] |
| RG-188-DS |RFW-3880- [inches] |
| RG-316/U |RFW-3881- [inches] |
| RG-316-DS |RFW-3882- [inches] |
| BELDEN 7805 |RFW-4931- [inches] |
| LMR-100A |RFW-3878- [inches] |
| WBC-100 |RFW-10395- [inches] |

ORDER INSTRUCTIONS

1. Choose your part number.
2. Fill in blank [] with your desired length in inches.
3. See page 19 for Standard Specifications.

Custom Assemblies — We will assemble ANY manufacturer's connector to ANY cable length.



SMB Plug to TNC Female Bulkhead



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-5121- | [inches] |
| RG-188A/U | RFW-4435- | [inches] |
| RG-188-DS | RFW-4436- | [inches] |
| RG-316/U | RFW-4437- | [inches] |
| RG-316-DS | RFW-4438- | [inches] |
| BELDEN 7805 | RFW-4936- | [inches] |
| LMR-100A | RFW-4439- | [inches] |
| WBC-100 | RFW-10400- | [inches] |

SMB R/A Plug to SMB R/A Plug



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|--------------|-------------|------------|
| RG-174A/U | RFW-5287- | [inches] |
| RG-188A/U | RFW-5288- | [inches] |
| RG-188A/U DS | RFW-5909- | [inches] |
| RG-316/U | RFW-5049- | [inches] |
| RG-316-DS | RFW-5910- | [inches] |
| BELDEN 7805 | RFW-4950- | [inches] |
| LMR-100A | RFW-5908- | [inches] |
| WBC-100 | RFW-10414- | [inches] |

SMB R/A Gold Plug to SMB R/A Gold Plug



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3990- | [inches] |
| RG-188A/U | RFW-3991- | [inches] |
| RG-316/U | RFW-3992- | [inches] |
| BELDEN 7805 | RFW-4947- | [inches] |
| LMR-100A | RFW-3993- | [inches] |
| WBC-100 | RFW-10411- | [inches] |

SMB R/A Plug to SMA Female



Fill in blank [inches] with your desired length in inches.

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3862- | [inches] |
| RG-188A/U | RFW-3863- | [inches] |
| RG-188-DS | RFW-3864- | [inches] |
| RG-316/U | RFW-3865- | [inches] |
| RG-316-DS | RFW-3866- | [inches] |
| BELDEN 7805 | RFW-4949- | [inches] |
| LMR-100A | RFW-3867- | [inches] |
| WBC-100 | RFW-10413- | [inches] |

SMB R/A Gold Plug to SMA Female

| | | |
|-------------|------------|------------|
| RG-174A/U | RFW-3868- | [inches] |
| RG-188A/U | RFW-3869- | [inches] |
| RG-316/U | RFW-3870- | [inches] |
| BELDEN 7805 | RFW-4943- | [inches] |
| LMR-100A | RFW-3871- | [inches] |
| WBC-100 | RFW-10407- | [inches] |

SMB R/A Gold Plug to SMB Bulkhead Jack



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3986- | [inches] |
| RG-188A/U | RFW-3987- | [inches] |
| RG-316/U | RFW-3988- | [inches] |
| BELDEN 7805 | RFW-4945- | [inches] |
| LMR-100A | RFW-3989- | [inches] |
| WBC-100 | RFW-10409- | [inches] |

SMB R/A Gold Plug to SMB R/A Gold Jack



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3994- | [inches] |
| RG-188A/U | RFW-3995- | [inches] |
| RG-316/U | RFW-3996- | [inches] |
| BELDEN 7805 | RFW-4946- | [inches] |
| LMR-100A | RFW-3997- | [inches] |
| WBC-100 | RFW-10410- | [inches] |

SMB R/A Gold Plug to MCX R/A Gold Plug



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3887- | [inches] |
| RG-188A/U | RFW-3888- | [inches] |
| RG-316/U | RFW-3889- | [inches] |
| BELDEN 7805 | RFW-4939- | [inches] |
| LMR-100A | RFW-3890- | [inches] |
| WBC-100 | RFW-10403- | [inches] |

SMB R/A Gold Plug to MMCX R/A Gold Plug



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3899- | [inches] |
| RG-188A/U | RFW-3900- | [inches] |
| RG-316/U | RFW-3901- | [inches] |
| BELDEN 7805 | RFW-4941- | [inches] |
| LMR-100A | RFW-3902- | [inches] |
| WBC-100 | RFW-10405- | [inches] |

SMB R/A Gold Plug to SMA Gold Male



Fill in blank [inches] with your desired length in inches

| Cable Type | Part Number | Length |
|-------------|-------------|------------|
| RG-174A/U | RFW-3807- | [inches] |
| RG-188A/U | RFW-3808- | [inches] |
| RG-316/U | RFW-3809- | [inches] |
| BELDEN 7805 | RFW-4944- | [inches] |
| LMR-100A | RFW-3810- | [inches] |
| WBC-100 | RFW-10408- | [inches] |